



UNIVERSAL SEMI-CONDUCTOR, INC.

Mailing Address: P.O. BOX 675, Sparta, New Jersey 07871
Shipping Address: 29 Lee Hill Road, Andover, New Jersey 07821
Phone: 973-347-5400 Toll Free: 800-222-2321
Fax: 973-347-0116 Email: usi@aol.com

www.universal-semi.com

Idler Wheel Catalog

The following pages can be used as a guide to our available stock.
Please refer to our web site or call to check on availability.



IDLER WHEELS AND ASSEMBLIES

IW - 1




RCA 164113
HITACHI 6886971

IW - 2



PANASONIC VXP0521

IW - 3



SHARP NIDL0005GEZZ

IW - 4



SHARP NIDL0006GEZZ

IW - 5



SANYO/ 143-0-4204-00300
FISHER 143-0-4204-00400

IW - 6



JVC PU48967B
AKAI, KENWOOD, SANSUI, DUAL

IW - 7



JVC PU51402A
NEC, KENWOOD, SANSUI, DUAL

IW - 8



JVC PU51380A-2
KENWOOD, SANSUI, DUAL

IW - 9



JVC PU55373
NEC, KENWOOD, SANSUI, DUAL

IW - 10



SANYO/FISHER 143-0-4204-00100

IW - 11



SANYO/FISHER 143-0-4804-00100

IW - 12



SANYO/FISHER 143-0-4904-00900

IW - 13



SANYO/FISHER 143-0-662T-01201

IW - 14



SANYO/FISHER 143-0-741T-20001

IW - 15



RCA 150650
HITACHI 6861482

IW - 16



RCA 158190, 162662
HITACHI 6875386, 6876043, 6876045

IW - 17



SAMSUNG 9000-250-3308V
GOLDSTAR EMERSON

IW - 18



PANASONIC VXP05116

IW - 19











































PANASONIC VXP0245





















IW - 20











































RCA 155739
PANASONIC VXP0054





















<p>IW - 21</p>  <p>PANASONIC VXP0174 RCA 144263</p>	<p>IW - 22</p>  <p>PANASONIC VXP0331 RCA 152683</p>	<p>IW - 23</p>  <p>PANASONIC VXP0344 RCA 148580</p>	<p>IW - 24</p>  <p>PANASONIC VXP0329 RCA 152674</p>
<p>IW - 25</p>  <p>SONY X-3653-315-0</p>	<p>IW - 26</p>  <p>SHARP NPLYV0107GEZZ</p>	<p>IW - 27</p>  <p>TOSHIBA 70326538</p>	<p>IW - 28</p>  <p>SANYO/FISHER 143-0-4204-00700</p>
<p>IW - 29</p>  <p>SANYO/FISHER 143-0-4904-02400</p>	<p>IW - 30</p>  <p>N.E.C. 161-808-01, 161-781-79</p>	<p>IW - 31</p>  <p>RCA 177194 HITACHI 6886792</p>	<p>IW - 32</p>  <p>SANYO/FISHER 143-0-662T-15620</p>
<p>IW - 33 CAM GEAR A</p>  <p>MITSUBISHI 641B093010</p>	<p>IW - 34 CAM GEAR B</p>  <p>MITSUBISHI 641B094010</p>	<p>IW - 35 GEAR 1</p>  <p>MITSUBISHI 641D710010</p>	<p>IW - 36 GEAR 2</p>  <p>MITSUBISHI 641D711010</p>
<p>IW - 37</p>  <p>GOLDSTAR 431-014A</p>	<p>IW - 38</p>  <p>GOLDSTAR 431-017A</p>	<p>IW - 39</p>  <p>SAMSUNG 9000-250-3308V</p>	<p>IW - 40</p>  <p>JVC PU56043-1-4</p>





















<p>IW - 41</p>  <p>JVC PU56044-1-4</p>	<p>IW - 42</p>  <p>SHARP NPLYV0051GEZZ</p>	<p>IW - 43</p>  <p>MITSUBISHI 522P00201</p>	<p>IW - 44</p>  <p>MITSUBISHI 522A00201</p>
<p>IW - 45</p>  <p>JVC PU55374-3-8</p>	<p>IW - 46</p>  <p>PANASONIC VXP0292</p>	<p>IW - 47</p> <p>DISCONTINUED</p>  <p>PANASONIC VXP0343,VXLS0081</p>	<p>IW - 48</p>  <p>PANASONIC VXL0997</p>
<p>IW - 49</p>  <p>PANASONIC VXP0463</p>	<p>IW - 50</p>  <p>RCA 150614 HITACHI 6861471</p>	<p>IW - 51</p>  <p>RCA 192242 SAMSUNG 6052-600-3101V</p>	<p>IW - 52</p>  <p>SANYO/ 143-0-662T-15621 FISHER 613 037 4905</p>
<p>IW - 53</p>  <p>SAMSUNG 5253-701-1105V</p>	<p>IW - 54</p>  <p>RCA 177206 HITACHI 6886824</p>	<p>IW - 55</p>  <p>SANYO/ 143-0-662T-14730 FISHER 613 037 4875</p>	<p>IW - 56</p>  <p>RCA 164089 HITACHI 6889931</p>
<p>IW - 57</p>  <p>GOLDSTAR 435-038A</p>	<p>IW - 58</p>  <p>DISCONTINUED</p> <p>HITACHI 6861505</p>	<p>IW - 59</p>  <p>RCA 147060,HITACHI 6413663</p>	<p>IW - 60</p>  <p>AKAI BL-B-353110</p>



<p>IW-61</p>  <p>mitsubishi/emerson 522B02002</p>	<p>IW-62</p>  <p>mitsubishi/emerson 522B01701</p>	<p>IW-63</p>  <p>mitsubishi/emerson 522B01801</p>	<p>IW-64</p>  <p>DAEWOO 97SA507200</p>
<p>IW-65</p>  <p>JVC PU58645-1-4</p>	<p>IW-66</p>  <p>PANASONIC VXL80454, VXL80383</p>	<p>IW-67</p>  <p>GOLD STAR 433-015A</p>	<p>IW-68</p>  <p>EMERSON 850A200005</p>
<p>IW-69</p>  <p>EMERSON 850A200004</p>	<p>IW-70</p>  <p>PANASONIC VXP-0523</p>	<p>IW-71</p>  <p>HITACHI 0897094/6897095</p>	<p>IW-72</p>  <p>FISHER GEAR 613 022 2534</p>
<p>IW-73 ORIGINAL</p>  <p>GOLDSTAR 321-397D ZENITH 812-2029-02</p>	<p>IW-74 ORIGINAL</p>  <p>GOLDSTAR 333-201B</p>	<p>IW-75 ORIGINAL</p>  <p>GOLDSTAR 333-208A ZENITH 917-863</p>	<p>IW-76 ORIGINAL</p>  <p>GOLDSTAR 337-005A</p>
<p>IW-77 ORIGINAL</p>  <p>GOLDSTAR 374-003A</p>	<p>IW-78 ORIGINAL</p>  <p>GOLDSTAR 374-005A ZENITH 928-129</p>	<p>IW-79 ORIGINAL</p>  <p>GOLDSTAR 386-139A</p>	<p>IW-80 ORIGINAL</p>  <p>GOLDSTAR 386-387B</p>








<p>IW-81 ORIGINAL</p>  <p>GOLDSTAR 433-007A</p>	<p>IW-82 ORIGINAL</p>  <p>GOLDSTAR 435-132A</p>	<p>IW-83 ORIGINAL</p>  <p>GOLDSTAR 435-169A</p>	<p>IW-84 ORIGINAL</p>  <p>GOLDSTAR 435-257B</p>
<p>IW-85 ORIGINAL</p>  <p>GOLDSTAR 435-291A ZENITH 834-341</p>	<p>IW-86 ORIGINAL</p>  <p>GOLDSTAR 435-318A ZENITH 834-364</p>	<p>IW-87 ORIGINAL</p>  <p>GOLDSTAR 435-450A</p>	<p>IW-88 ORIGINAL</p>  <p>JVC PQ30028 ZENITH 834-163</p>
<p>IW-89 ORIGINAL</p>  <p>JVC PQ40059 ZENITH 834-159</p>	<p>IW-90 ORIGINAL</p>  <p>JVC PQ40060 ZENITH 834-160</p>	<p>IW-91 ORIGINAL</p>  <p>JVC PQ40066-1-2 ZENITH 834-164-01</p>	<p>IW-92 ORIGINAL</p>  <p>JVC PQ40067-1-2 ZENITH 834-165-01</p>
<p>IW-93 ORIGINAL</p>  <p>JVC PQ40074 ZENITH 917-694</p>	<p>IW-94 ORIGINAL</p>  <p>JVC PQ40076-2 ZENITH 917-750</p>	<p>IW-95 ORIGINAL</p>  <p>JVC PQ43555C-10</p>	<p>IW-96 ORIGINAL</p>  <p>JVC PQ43570B</p>
<p>IW-97 ORIGINAL</p>  <p>JVC PTU96031-678C</p>	<p>IW-98</p>  <p>PANASONIC VDGS0200</p>	<p>IW-99</p>  <p>SAMSUNG 66054-609-410</p>	<p>IW-100</p>  <p>mitsubishi 641C803010</p>

<p>IW-101 ORIGINAL</p>  <p>JVC PQ43542D-4</p>	<p>IW-102 ORIGINAL</p>  <p>JVC PQ43567A-13</p>	<p>IW-103 ORIGINAL</p>  <p>SANYO/ FISHER 613-077-3586</p>	<p>IW-104 ORIGINAL</p>  <p>SHARP NGERH1073GEZZ</p>
<p>IW-105 ORIGINAL</p>  <p>SHARP NGERH1076GEZZ</p>	<p>IW-106 ORIGINAL</p>  <p>SHARP NGERH1118GEZZ</p>	<p>IW-107</p>  <p>PANASONIC VXL1856</p>	<p>IW-108</p>  <p>SANYO 613-022-0141</p>
<p>IW-109</p>  <p>SHARP NGERH1057GEZZ</p>	<p>IW-110</p>  <p>SHARP NGERH1122GEZZ</p>	<p>IW-111</p>  <p>SHARP NGERH1128GEZZ</p>	<p>IW-112</p>  <p>JVC PU60953-1-1</p>
<p>IW-113</p>  <p>SANYO FISHER 613-022-0066</p>	<p>IW-114</p>  <p>PANASONIC VXL1910</p>	<p>IW-115 ORIGINAL</p>  <p>SONY X-2625-356-2</p>	<p>IW-116 ORIGINAL</p>  <p>SONY X-3727-782-1</p>
<p>IW-117 ORIGINAL</p>  <p>SONY X-3942-218-4</p>	<p>IW-118 ORIGINAL</p>  <p>SONY X-4920-346-1</p>	<p>IW-119 ORIGINAL</p>  <p>SONY 3-736-015-01</p>	<p>IW-120 ORIGINAL</p>  <p>SONY 3-736-116-01</p>





















<p>IW-121 ORIGINAL</p>  <p>SONY 3-736-143-01</p>	<p>IW-122 ORIGINAL</p>  <p>SONY 3-736-176-01</p>	<p>IW-123 ORIGINAL</p>  <p>SONY 3-736-177-01</p>	<p>IW-124 ORIGINAL</p>  <p>Gear SONY 3-684-163-01</p>
<p>IW-125 ORIGINAL</p>  <p>Bracket Assembly Goldstar 321-369A</p>	<p>IW-126 ORIGINAL</p>  <p>Hitachi 6804834 6896954 RCA191-367</p>	<p>IW-127 ORIGINAL</p>  <p>Worm Gear SONY 2-643-405-01</p>	<p>IW-128 ORIGINAL</p>  <p>Cam Gear JVC PQ32413-1-6</p>
<p>IW-129 ORIGINAL</p>  <p>Loading Arm JVC PQ43537B</p>	<p>IW-130 ORIGINAL</p>  <p>Sub Brake Ass'y JVC PQ43583A-3</p>	<p>IW-131 ORIGINAL</p>  <p>Idler Gear JVC PU60618-1-3 Zenith 834-296</p>	<p>IW-132 ORIGINAL</p>  <p>DISCONTINUED</p> <p>Gear Assembly JVC PU61004-1-3</p>
<p>IW-133 ORIGINAL</p>  <p>Clutch Unit JVC PU61005-1-6</p>	<p>IW-134 ORIGINAL</p>  <p>Clutch Unit JVC PU61245-1-3</p>	<p>IW-135 ORIGINAL</p>  <p>Gear Goldstar 435-239A</p>	<p>IW-136 ORIGINAL</p>  <p>Lever Goldstar 437-004A</p>
<p>IW-137 ORIGINAL</p>  <p>Sharp Arm MARMP0032GEZZ</p>	<p>IW-138 ORIGINAL</p>  <p>Sharp Lever MLEVP0134GEZZ</p>	<p>IW-139 ORIGINAL</p>  <p>Gear Assembly Hitachi 6405183</p>	<p>IW-140 ORIGINAL</p>  <p>Hitachi Clutch 6405191</p>

<p>IW-141 ORIGINAL</p>  <p>Cam Control JVC PQ20822-2-7</p>	<p>IW-142 ORIGINAL</p>  <p>Idler Assembly Goldstar 321-218A</p>	<p>IW-143 ORIGINAL</p>  <p>Bracket Ass'y Goldstar 321-223A</p>	<p>IW-144 ORIGINAL</p>  <p>Bracket Ass'y Goldstar 321-232A</p>
<p>IW-145 ORIGINAL</p>  <p>Idler Assembly Goldstar 431-021A</p>	<p>IW-146 ORIGINAL</p>  <p>Gear Goldstar 432-036A</p>	<p>IW-147 ORIGINAL</p>  <p>Ass'y arm Goldstar 256-473A</p>	<p>IW-148 ORIGINAL</p>  <p>Load Assembly Goldstar 435-107B</p>
<p>IW-149 ORIGINAL</p>  <p>Idler Gear Goldstar 435-130A</p>	<p>IW-150 ORIGINAL</p>  <p>Arm Gear Goldstar 435-134A</p>	<p>IW-151 ORIGINAL</p>  <p>Gear RCA 190108 Panasonic VMLS0508</p>	<p>IW-152 ORIGINAL</p>  <p>Arm Gear Goldstar 435-148A</p>
<p>IW-153 ORIGINAL</p>  <p>Panasonic Reel Idler VXP0675</p>	<p>IW-154 ORIGINAL</p>  <p>Gear Pansnc.VDGS0137 RCA 190054</p>	<p>IW-155 ORIGINAL</p> <p>DISCONTINUED</p>  <p>USE IW-274</p> <p>Gear SONY 3-958-156-02</p>	<p>IW-156 ORIGINAL</p>  <p>Idler Gear Pansnc.VDGS0134 RCA 190051</p>
<p>IW-157 ORIGINAL</p>  <p>Reel Table Assembly SONY X-3727-952-1</p>	<p>IW-158 ORIGINAL</p>  <p>Slider Sony 4-920-289-01</p>	<p>IW-159 ORIGINAL</p>  <p>Gear Panasonic VXPS0372 RCA 225159</p>	<p>IW-160 ORIGINAL</p>  <p>Clutch Assembly JVC YU40624-1-1</p>





















<p>IW-161 ORIGINAL</p>  <p>Clutch Assembly JVC YU41459-1-2</p>	<p>IW-162 ORIGINAL</p>  <p>Worm Ass'y Pansnc.VXPS0146 RCA 185427</p>	<p>IW-163 ORIGINAL</p>  <p>Gear RCA 250193 Panasonic VMLS0749</p>	<p>IW-164 ORIGINAL</p>  <p>Gear RCA 190109 Panasonic VMLS0634</p>
<p>IW-165 ORIGINAL</p>  <p>Gear Pansnc. VDGS0224 RCA 194385</p>	<p>IW-166 ORIGINAL</p>  <p>Gear Panas.VXPS0310 RCA 206981</p>	<p>IW-167 ORIGINAL</p>  <p>Gear Panasonic VDGS0251</p>	<p>IW-168 ORIGINAL</p>  <p>Idler Gear Pansnc. VDGS0138 RCA 190055</p>
<p>IW-169 ORIGINAL</p>  <p>Idler Gear Panasnc. VDGS0140 RCA 190057</p>	<p>IW-170 ORIGINAL</p>  <p>Idler Gear Panasnc. VDGS0136 RCA 190053</p>	<p>IW-171 ORIGINAL</p>  <p>Gear Assembly RCA 230519 DAEWOO 97SA301400 EMERSON 97SA301400</p>	<p>IW-172 ORIGINAL</p>  <p>Reel Table Assembly SONY X-3727-951-9</p>
<p>IW-173 ORIGINAL</p>  <p>Slide Plate RCA 225141</p>	<p>IW-174 ORIGINAL</p>  <p>Slide Plate RCA 212497</p>	<p>IW-175 ORIGINAL</p>  <p>Eject Gear Kit RCA 221066 Samsung62203-0025-01</p>	<p>IW-176 ORIGINAL</p>  <p>Load Gear Goldstar 435-234A</p>
<p>IW-177 ORIGINAL</p>  <p>Gear Goldstar 435-246A</p>	<p>IW-178 ORIGINAL</p>  <p>Worm Wheel Goldstar 433-023A</p>	<p>IW-179 ORIGINAL</p>  <p>Cam Gear Goldstar 435-042A/B</p>	<p>IW-180 ORIGINAL</p>  <p>Gear RCA 218910</p>

<p>IW-181 ORIGINAL</p>  <p>Brake Assembly Goldstar 338-078A</p>	<p>IW-182 ORIGINAL</p>  <p>Gear RCA 225117</p>	<p>IW-183 ORIGINAL</p>  <p>Arm Assembly Goldstar 386-296C</p>	<p>IW-184 ORIGINAL</p>  <p>Center Clutch Panasonic VXP0600</p>
<p>IW-185 ORIGINAL</p>  <p>Idler Gear Panasonic VDGS0254</p>	<p>IW-186 ORIGINAL</p>  <p>Idler Gear Emerson 850A200051</p>	<p>IW-187 ORIGINAL</p>  <p>Clutch Assembly Emerson 850A200049</p>	<p>IW-188 ORIGINAL</p>  <p>Clutch Assembly Emerson 850A200050</p>
<p>IW-189 ORIGINAL</p>  <p>Load Arm RCA 206975 Panasonic VXLS0850</p>	<p>IW-190 ORIGINAL</p>  <p>Load Arm RCA 206976 Panasonic VXLS0852</p>	<p>IW-191 ORIGINAL</p>  <p>Sharp Gear NGERH1219GEZZ</p>	<p>IW-192 ORIGINAL</p>  <p>Sharp Gear NGERH1226GEOO</p>
<p>IW-193 ORIGINAL</p>  <p>Sharp Gear NGERH1227GEZZ</p>	<p>IW-194 ORIGINAL</p>  <p>Idler Assembly SONY 3-945-697-03</p>	<p>IW-195 ORIGINAL</p>  <p>Loading Arm JVC PQ46337A-7</p>	<p>IW-196 ORIGINAL</p>  <p>Plate Ass'y JVC PQ44581B</p>
<p>IW-197 ORIGINAL</p>  <p>Plate Ass'y JVC PQ44326A-3</p>	<p>IW-198 ORIGINAL</p>  <p>JVC Control Plate PQ11657-1-15</p>	<p>IW-199 ORIGINAL</p>  <p>Panasonic Worm Wheel VDGS0293, VDGS0323</p>	<p>IW-200 ORIGINAL</p>  <p>JVC Guide Arm Assembly PQ46325B</p>




<p>IW-201 ORIGINAL</p>  <p>Sharp Gear NGERH1225GEZZ</p>	<p>IW-202 ORIGINAL</p>  <p>JVC Guide Bracket E408102-001</p>	<p>IW-203 ORIGINAL</p>  <p>Sony Cam Elevator 3-952-182-01</p>	<p>IW-204 ORIGINAL</p>  <p>Threading Gear (Right) 3-736-148-01</p>
<p>IW-205 ORIGINAL</p>  <p>Sony Roller Ring 3-668-963-00/03</p>	<p>IW-206 ORIGINAL</p>  <p>JVC Idler Gear Unit PU61246-1-5</p>	<p>IW-207 ORIGINAL</p>  <p>Sony (T) Loading Gear 3-958-485-02</p>	<p>IW-208 ORIGINAL</p>  <p>Hitachi Belt & Pulley Kit 4589074</p>
<p>IW-209 ORIGINAL</p>  <p>Sharp Gear NGERH1074GEZZ</p>	<p>IW-210 ORIGINAL</p>  <p>Sony Main Slider 3-958-163-04</p>	<p>IW-211 ORIGINAL</p>  <p>Daewoo Clutch Assembly 97SA387600</p>	<p>IW-212 ORIGINAL</p>  <p>RCA Gear 202036</p>
<p>IW-213 ORIGINAL</p>  <p>Hitachi Loading Block 4586652 7468854</p>	<p>IW-214 ORIGINAL</p>  <p>Hitachi arm 6823663</p>	<p>IW-215 ORIGINAL</p>  <p>Sanyo/Fisher Gear 613-152-0172 613-154-8794</p>	<p>IW-216 ORIGINAL</p>  <p>JVC T. Arm Lever PQ35012-1-5</p>
<p>IW-217 ORIGINAL</p>  <p>Sharp Gear NGERW1032</p>	<p>IW-218 ORIGINAL</p>  <p>RCA Gear 212275</p>	<p>IW-219 ORIGINAL</p>  <p>Zenith Gear Kit 834-402</p>	<p>IW-220 ORIGINAL</p>  <p>Sony Gear 3-736-147-01</p>

<p>IW-221 ORIGINAL</p>  <p>Sony Gear Arm Assembly X-3727-926-1</p>	<p>IW-222 ORIGINAL</p>  <p>JVC Lift Rail 30050441T</p>	<p>IW-223 ORIGINAL</p>  <p>Sony Gear 3-733-394-01</p>	<p>IW-224 ORIGINAL</p>  <p>Sony Gear 3-945-700-01</p>
<p>IW-225 ORIGINAL</p>  <p>JVC Lever Assembly PQ46342B/A6/C9</p>	<p>IW-226 ORIGINAL</p>  <p>Panasonic Brake VXZ0189</p>	<p>IW-227 ORIGINAL</p>  <p>Panasonic Idler VXP0537</p>	<p>IW-228 ORIGINAL</p>  <p>Panasonic Brake VXZ0265</p>
<p>IW-229 ORIGINAL</p>  <p>Motor Block Panasonic VXKS0778 RCA 225228</p>	<p>IW-230 ORIGINAL</p>  <p>Panasonic Lever RXL0049</p>	<p>IW-231 ORIGINAL</p>  <p>RCA Clutch 210841</p>	<p>IW-232 ORIGINAL</p>  <p>RCA Shaft 182920</p>
<p>IW-233 ORIGINAL</p>  <p>RCA Motor Assembly 189074</p>	<p>IW-234 ORIGINAL</p>  <p>RCA Arm 192873</p>	<p>IW-235 ORIGINAL</p>  <p>Panasonic Gear RDG0067</p>	<p>IW-236 ORIGINAL</p>  <p>Panasonic Gear VXP0599</p>
<p>IW-237 ORIGINAL</p>  <p>Panasonic Brake VXZ0314</p>	<p>IW-238 ORIGINAL</p>  <p>Panasonic Brake VXZ0270</p>	<p>IW-239 ORIGINAL</p>  <p>Panasonic Head Cleaning VXL2263</p>	<p>IW-240 ORIGINAL</p>  <p>Panasonic Cleaner VXP1341</p>

<p>IW-241 ORIGINAL</p>  <p>Hitachi Gear 6897265</p>	<p>IW-242 ORIGINAL</p>  <p>Hitachi Gear Assembly 6401043</p>	<p>IW-243 ORIGINAL</p>  <p>Hitachi Gear Assembly 6804982</p>	<p>IW-244 ORIGINAL</p>  <p>Hitachi Gear Assembly 6896971</p>
<p>IW-245 ORIGINAL</p>  <p>Sony Right Gear Assembly X-3728-843-1</p>	<p>IW-246 ORIGINAL</p>  <p>Sony Gear 4-957-284-01</p>	<p>IW-247 ORIGINAL</p>  <p>Panasonic Gear RDK0007-1</p>	<p>IW-248 ORIGINAL</p>  <p>Panasonic Slide Plate VXAS1709</p>
<p>IW-249 ORIGINAL</p>  <p>Hitachi Arm 7580791</p>	<p>IW-250 ORIGINAL</p>  <p>Panasonic Gear VDGS0254</p>	<p>IW-251 ORIGINAL</p>  <p>NOTE: Different from 3-958-156-02 Sony Gear 3-958-156-03</p>	<p>IW-252 ORIGINAL</p>  <p>Goldstar Gear 435-146A</p>
<p>IW-253 ORIGINAL</p>  <p>Sanyo/Fisher Gear Assembly 613-100-4689</p>	<p>IW-254 ORIGINAL</p>  <p>Sanyo/Fisher Brake Assembly 613-038-0197</p>	<p>IW-255 ORIGINAL</p>  <p>Sanyo/Fisher Gear 613-054-6937</p>	<p>IW-256 ORIGINAL</p>  <p>Sanyo/Fisher Gear 613-022-2428 613-090-6373</p>
<p>IW-257 ORIGINAL</p>  <p>Sanyo/Fisher Gear 613-090-6380</p>	<p>IW-258 ORIGINAL</p>  <p>Sanyo/Fisher Bracket 613-022-2015</p>	<p>IW-259 ORIGINAL</p>  <p>Sanyo/Fisher Gear 613-103-2651</p>	<p>IW-260 ORIGINAL</p>  <p>Sanyo/Fisher Gear 613-077-3647</p>

<p>IW-261 ORIGINAL</p>  <p>Sanyo/Fisher Gear 613-135-7662</p>	<p>IW-262 ORIGINAL</p>  <p>Sanyo/Fisher Gear Assembly 613-022-2619</p>	<p>IW-263 ORIGINAL</p>  <p>Sanyo/Fisher Cleaner 613-119-8562</p>	<p>IW-264 ORIGINAL</p>  <p>Sanyo/Fisher Gear 613-100-4665</p>
<p>IW-265 ORIGINAL</p>  <p>Sanyo/Fisher Brake Assembly 613-081-7518</p>	<p>IW-266 ORIGINAL</p>  <p>Sanyo/Fisher Gear Assembly 613-022-0134</p>	<p>IW-267 ORIGINAL</p>  <p>Toshiba Lever 70031477</p>	<p>IW-268 ORIGINAL</p>  <p>Hitachi Gear Assembly 6807981</p>
<p>IW-269 ORIGINAL</p>  <p>Hitachi Gear Assembly 4589373</p>	<p>IW-270 ORIGINAL</p>  <p>Sanyo/Fisher Gear Assembly 613-102-0900 613-130-9890</p>	<p>IW-271 ORIGINAL</p>  <p>Sanyo/Fisher Joint Assembly 614-210-3999</p>	<p>IW-272 ORIGINAL</p>  <p>Sanyo/Fisher Gear 614-247-9087</p>
<p>IW-273 ORIGINAL</p>  <p>Sanyo/Fisher Gear 614-253-9071</p>	<p>IW-274 ORIGINAL</p>  <p>Sony Maintenance Kit Modification for IW-155 Contains 5 Gears A-7040-474-C</p>	<p>IW-275 ORIGINAL</p>  <p>Sony Arm 3-736-140-01</p>	<p>IW-276 ORIGINAL</p>  <p>Sony Arm 3-736-142-01</p>
<p>IW-277 ORIGINAL</p>  <p>Sony Gear 3-946-922-01</p>	<p>IW-278 ORIGINAL</p>  <p>DISCONTINUED</p> <p>Toshiba Gear Assembly 70790029</p>	<p>IW-279 ORIGINAL</p>  <p>Panasonic Lever RXL0050</p>	<p>IW-280 ORIGINAL</p>  <p>Panasonic Gear VDGS0141</p>



IW-281 ORIGINAL	IW-282 ORIGINAL	IW-283 ORIGINAL	
 <p>Panasonic Head Plate Kit VXA3980Kit</p>	 <p>Toshiba Lever 70363446</p>	 <p>Goldstar Motor Assembly 414-104A</p>	